


Advanced Fluid Mechanics

BME GEÁT MW01

Dr. Gergely Kristóf
 Department of Fluid Mechanics, BME
 February 2014.

Timeline



Foreseeable program

Course week	Topics
1.	Overview of the fundamentals of fluid mechanics. Vorticity transport equation.
2.	Irrrotational flows, Darcy flow, Wells.
3.	Joukowski transformation.
4.	Boundary layers. Similarity solutions for laminar and turbulent boundary layers.
5.	Transition. Turbulent boundary layers. BL control.
6.	Fundamentals of gasdynamics. Wave phenomena. Izentropic flow
7.	Normal shock waves
8.	Oblique shock waves, wave reflection. Prandtl-Meyer expansion, Supersonic jets.
9.	Overview of computational fluid dynamics (CFD). Turbulence models.
10.	Pipe networks, pipe transients
11.	Atmospheric flows
12.	Case studies: Tamás Lajos & Gergely Kristóf
13.	Tamás Lajos: Aerosoils 1.
14.	Tamás Lajos: Aerosoils 2.

References

- 1) Lamb H: Hydrodynamics, 1932.
- 2) Schlichting H: Boundary Layer Theory, 1955.
- 3) Shapiro A. H: The Dynamics and Thermodynamics of Compressible Fluid Flow, 1953.
- 4) Streeter V. L, Wylie E. B: Fluid Mechanics, McGraw-Hill, 1975.
- 5) Ferziger J. H, Peric M: Computational Methods for Fluid Dynamics, Springer, ISBN 3-540-42074-6, 2002.

Lecture handouts:

http://www.ara.bme.hu/oktatas/tantargy/NEPTUN/BMEGEATMW01/2013-2014-II/ea_lecture/

1. Introduction, review of vortical flows

Dr. Gergely Kristóf
Dept. of Fluid Mechanics, BME
February, 2009.

Acceleration of a fluid parcel


Velocity components: $\vec{v}(t, \vec{r}) = u(t, x, y, z)\vec{i} + v(t, x, y, z)\vec{j} + w(t, x, y, z)\vec{k}$

$$du = \frac{\partial u}{\partial t} dt + \frac{\partial u}{\partial x} dx + \frac{\partial u}{\partial y} dy + \frac{\partial u}{\partial z} dz$$

For a fluid parcel: $\frac{dx}{dt} = u, \frac{dy}{dt} = v, \frac{dw}{dt} = w$

$$\left. \begin{aligned} \frac{du}{dt} &= \frac{\partial u}{\partial t} + \vec{v} \cdot \nabla u \\ \frac{dv}{dt} &= \frac{\partial v}{\partial t} + \vec{v} \cdot \nabla v \\ \frac{dw}{dt} &= \frac{\partial w}{\partial t} + \vec{v} \cdot \nabla w \end{aligned} \right\} \begin{array}{l} \text{velocity gradient tensor} \\ \downarrow \\ \frac{d\vec{v}}{dt} = \frac{\partial \vec{v}}{\partial t} + \vec{v} \cdot \nabla \vec{v} \\ \uparrow \quad \downarrow \\ \text{local acceleration} \quad \text{convective acceleration} \end{array}$$

Vortices




Circulation: $\Gamma = \oint_S \vec{v} \cdot d\vec{s}$

Vorticity: $\vec{\omega} = \nabla \times \vec{v} = \begin{pmatrix} w'_y - v'_z \\ u'_z - w'_x \\ v'_x - u'_y \end{pmatrix}$

From the Stokes theorem we also know that: $\Gamma = \int_A \vec{\omega} \cdot d\vec{A}$

Thomson: If s is a fluid line of a perfect fluid, then $\frac{d\Gamma}{dt} = 0$



Vorticity transport equation for constant property Newtonian fluid

(ρ and ν are constants)

The continuity equation simplifies to: $\nabla \cdot \vec{v} = 0$

By taking the curl of the Navier-Stokes equation:

$$\frac{d\vec{v}}{dt} = \frac{\partial \vec{v}}{\partial t} + \vec{v} \cdot \nabla \vec{v} = -\frac{1}{\rho} \nabla p + \vec{g} + \nu_0 \Delta \vec{v}$$

$\nabla \times \dots$

we obtain

$$\frac{d\vec{\omega}}{dt} = \frac{\partial \vec{\omega}}{\partial t} + \vec{v} \cdot \nabla \vec{\omega} = \nabla \times \vec{g} + \nu_0 \Delta \vec{\omega} + \underbrace{\vec{\omega} \cdot \nabla \vec{v}}_{\text{vortex stretching}} - \underbrace{\vec{\omega} \nabla \cdot \vec{v}}_0$$

in which

- $\frac{\partial \vec{\omega}}{\partial t}$ is the vorticity transport
- $\vec{v} \cdot \nabla \vec{\omega}$ is the vorticity transport
- $\nabla \times \vec{g}$ is 0, if \vec{g} is irrotational
- $\nu_0 \Delta \vec{\omega}$ is vortex diffusion
- $\vec{\omega} \cdot \nabla \vec{v}$ is vortex stretching
- $-\vec{\omega} \nabla \cdot \vec{v}$ is 0.

Curl of the convective acceleration term in 2D flow

$$\vec{\omega} = \begin{pmatrix} w'_y - v'_z \\ u'_z - w'_x \\ v'_x - u'_y \end{pmatrix} \rightarrow \omega = v'_x - u'_y$$

$$\nabla \times (\vec{v} \cdot \nabla \vec{v}) = \nabla \times \begin{pmatrix} u'_x & u'_y \\ v'_x & v'_y \end{pmatrix} \begin{pmatrix} u \\ v \end{pmatrix} = (v'_x u + v'_y v)_x - (u'_x u + u'_y v)_y$$

$$\begin{pmatrix} v''_{xx} - u''_{xy} \\ v''_{yx} - u''_{yy} \end{pmatrix} \begin{pmatrix} u \\ v \end{pmatrix} + \underbrace{v'_x u'_x - u'_x u'_y + v'_y v'_x - u'_y v'_y}_{\omega(u'_x + v'_y) = 0}$$

$$\nabla \times (\vec{v} \cdot \nabla \vec{v}) = \vec{v} \cdot \nabla \omega + \omega \nabla \cdot \vec{v}$$

Curl of the convective acceleration term in 3D flow

$$\nabla \times (\vec{v} \cdot \nabla \vec{v}) = \nabla \times \begin{pmatrix} u'_x & u'_y & u'_z \\ v'_x & v'_y & v'_z \\ w'_x & w'_y & w'_z \end{pmatrix} \begin{pmatrix} u \\ v \\ w \end{pmatrix} = \vec{\omega} = \nabla \times \begin{pmatrix} u \\ v \\ w \end{pmatrix} = \begin{pmatrix} w'_y - v'_z \\ u'_z - w'_x \\ v'_x - u'_y \end{pmatrix}$$

$$= \begin{pmatrix} w''_{xy} - v''_{xz} & w''_{yy} - v''_{yz} & w''_{zy} - v''_{zz} \\ u''_{xz} - w''_{xx} & u''_{yz} - w''_{yx} & u''_{zz} - w''_{zx} \\ v''_{xx} - u''_{xy} & v''_{yx} - u''_{yy} & v''_{zx} - u''_{zy} \end{pmatrix} \begin{pmatrix} u \\ v \\ w \end{pmatrix} + \begin{pmatrix} w'_x u'_y - v'_x u'_z + w'_y v'_y - v'_y v'_z + w'_z w'_y - v'_z w'_z \\ u'_x u'_z - w'_x u'_x + u'_y v'_z - w'_y v'_x + u'_z w'_z - w'_z w'_x \\ v'_x u'_x - u'_x u'_y + v'_y v'_x - u'_y v'_y + v'_z w'_x - u'_z w'_y \end{pmatrix}$$

$$\nabla \times (\vec{v} \cdot \nabla \vec{v}) = \vec{\omega} = \begin{pmatrix} \alpha \\ \beta \\ \gamma \end{pmatrix} = \begin{pmatrix} w'_y - v'_z \\ u'_z - w'_x \\ v'_x - u'_y \end{pmatrix}$$


$$\begin{pmatrix} \alpha'_x & \alpha'_y & \alpha'_z \\ \beta'_x & \beta'_y & \beta'_z \\ \gamma'_x & \gamma'_y & \gamma'_z \end{pmatrix} \begin{pmatrix} u \\ v \\ w \end{pmatrix} + \begin{pmatrix} w'_x u'_y - v'_x u'_z - u'_x w'_y + u'_x v'_z \\ u'_y v'_z - w'_y v'_x - v'_y u'_z + v'_y w'_x \\ v'_z w'_x - u'_z w'_y - w'_z v'_x + w'_z u'_y \end{pmatrix} + \begin{pmatrix} \alpha \\ \beta \\ \gamma \end{pmatrix} (u'_x + v'_y + w'_z)$$

$$\vec{\omega} \cdot \nabla \vec{v} = \begin{pmatrix} u'_x w'_y - u'_x v'_z + u'_y u'_z - u'_y w'_x + u'_z v'_x - u'_z u'_y \\ v'_x w'_y - v'_x v'_z + v'_y u'_z - v'_y w'_x + v'_z v'_x - v'_z u'_y \\ w'_x w'_y - w'_x v'_z + w'_y u'_z - w'_y w'_x + w'_z v'_x - w'_z u'_y \end{pmatrix}$$

$$\nabla \times (\vec{v} \cdot \nabla \vec{v}) = \vec{v} \cdot \nabla \vec{\omega} - \vec{\omega} \cdot \nabla \vec{v} + \vec{\omega} \nabla \cdot \vec{v}$$

Vortex stretching

Evolution of a fluid line of elementary length



$$\vec{v}(t, \vec{r} + \vec{s}) - \vec{v}(t, \vec{r}) = \vec{s} \cdot \nabla \vec{v}$$

$$\frac{d\vec{s}}{dt} = \vec{s} \cdot \nabla \vec{v}$$

Vorticity transport equation for irrotational body force and zero viscosity:


$$\frac{d\vec{\omega}}{dt} = \vec{\omega} \cdot \nabla \vec{v}$$

The direction of \vec{s} is arbitrarily chosen.

Both vectors evolve according to the same transport equation, hence, in inviscid flow, the vorticity vector behaves in the same way as an infinitesimal fluid line element. (Helmholtz)

Thus, ω will grow, when the fluid line is stretched.

Problem #1.1



Compare a 2D confuser (of slab symmetry) with an axial symmetric confuser:

- What components of the vorticity vector are non-zero?
Use cylindrical coordinates (x, r, ϕ) in the axisymmetric case!
- In what proportion does the length of a fluid element change?
- In what proportion will the components of the vorticity change if the vortex diffusion is negligible?

To the solution

Vortex diffusion

The vorticity transport equation for a 2D flow of a constant property Newtonian fluid:

$$\frac{d\omega}{dt} = \frac{\partial \omega}{\partial t} + \vec{v} \cdot \nabla \omega = \nu_0 \Delta \omega$$

$$\nu_0 = \frac{\mu}{\rho} \left[\frac{m^2}{s} \right]$$

kinematical viscosity

Is in full analogy with the heat transport equation:


$$\frac{dT}{dt} = \frac{\partial T}{\partial t} + \vec{v} \cdot \nabla T = a \Delta T$$

$$a = \frac{\lambda}{\rho c} \left[\frac{m^2}{s} \right]$$

heat diffusion coefficient

The kinematical viscosity can be regarded as a vorticity diffusion coefficient. These two phenomena are in full analogy.

Boundary layer over a flat plate



Vorticity is continuously produced on the wall surface due to the no-slip condition, and it is conducted into the main stream by the viscosity.

Conclusion

The vorticity transport equation for incompressible fluids reads:

$$\frac{d\vec{\omega}}{dt} = \nabla \times \vec{g} + \nu_0 \Delta \vec{\omega} + \vec{\omega} \cdot \nabla \vec{v}$$

Origin of vorticity:

- Boundary conditions (wall shear)
- Non conservative forces (eg. Coriolis force)

Redistribution of vorticity:

- Vortex stretching
- Vortex diffusion

2. Irrotational flows

Dr. Gergely Kristóf
Department of Fluid Mechanics, BME
February, 2009.

Irrotational flows

Shape of the streamlines?
Pressure and velocity distributions?

Most analytic solutions have been developed for irrotational flows.
Lamb, H: Hydrodynamics, 1932. (First edition: 1879.)

Flows originated from a volume containing fluid at rest is an irrotational flow until the vorticity generated by walls penetrates the flow field.


„The irrotational motion of a liquid occupying a simply-connected region has less kinetic energy than any other motion consistent with the same normal motion of the boundary.” (W.Thomson, 1849)

If the velocity field is rotation free: $\nabla \times \vec{v} = 0$

we can define velocity-potential function ϕ as: $\vec{v} = \nabla \phi$

(This holds for compressible flows as well.)

Some application examples



- Flow close to the extraction point
- Flow around airfoils
- Darcy flow, wells
- Drinking water reservoirs

Calculation of the pressure field

Pressure distribution in ideal fluid ($\mu=0, \rho=\text{const.}$) can be obtained from the Bernoulli principle:

$$p_2 - p_1 = \frac{\rho}{2} (v_1^2 - v_2^2) + \rho g (z_1 - z_2)$$

The equation of motion for Darcy flow:

$$\vec{v} = -\frac{k}{\mu} \nabla(p + \rho g z) \longrightarrow \phi = -k \frac{p + \rho g z}{\mu}$$

In which the density (ρ), the permeability (k) and the dynamic viscosity (μ) are constant values and the velocity is defined as the surface intensity of the volume flow rate:

$$Q = \int \vec{v} d\vec{A}$$

$$p_2 - p_1 = \frac{\mu}{k} (\phi_1 - \phi_2) + \rho g (z_1 - z_2)$$

Velocity potential for constant density fluid flow

Continuity equation: $\nabla \cdot \vec{v} = 0$

$$\nabla \cdot (\nabla \phi) = \Delta \phi = 0$$

ϕ is an harmonic function (fulfilling the Laplace equation).


An important example: velocity potential of a point source:

$$\vec{v} = \frac{Q}{4\pi r^2} \vec{e}_r \longrightarrow \phi = -\frac{Q}{4\pi r} + \text{Const.}$$

Superposition principle

The governing equations are linear, therefore we can utilize the superposition principle.

E.g. double source (doublet).



Any irrotational flow can be regarded as a result of a distribution of sources and doublets over the boundary.

The intensity distribution is still a question.
We can utilize the boundary element method ...

Stream function

The continuity equation of a **constant density** fluid is automatically fulfilled, if the velocity field can be derived from an existing $\vec{\psi}$ vector potential function:

Def: $\vec{v} = \nabla \times \vec{\psi}$

$$\nabla \cdot \vec{v} = \nabla \cdot \nabla \times \vec{\psi} \equiv 0$$

Ψ is a scalar function in 2 spatial dimensions and called the „stream function“ in 2D flow situations. Only the z component is non-zero:


$$\vec{v} = \begin{pmatrix} \frac{\partial \psi_z}{\partial y} - \frac{\partial \psi_y}{\partial z} \\ \frac{\partial \psi_x}{\partial z} - \frac{\partial \psi_z}{\partial x} \\ \frac{\partial \psi_y}{\partial x} - \frac{\partial \psi_x}{\partial y} \end{pmatrix}$$

u and v are the x and y components of the velocity vector:

$$u = \frac{\partial \psi}{\partial y} \quad \text{and} \quad v = -\frac{\partial \psi}{\partial x}$$

Ψ makes much more sense in 2D, because the definition decreases the number of unknown scalar fields.

The stream function in 2D



The total differential of the stream function:

$$d\psi = \frac{\partial \psi}{\partial x} dx + \frac{\partial \psi}{\partial y} dy$$

$$\frac{\partial \psi}{\partial x} = -v \quad \text{and} \quad \frac{\partial \psi}{\partial y} = u$$

$$d\psi = -v dx + u dy$$

Ψ expresses volume flow-rate between A and B (in a 1m wide domain):

$$Q_{A-B} = \psi_B - \psi_A$$

There is no flow through the iso-lines of Ψ , therefore these are **streamlines**.

The continuity in 2D: $\frac{\partial u}{\partial x} + \frac{\partial v}{\partial y} = \frac{\partial^2 \psi}{\partial x \partial y} - \frac{\partial^2 \psi}{\partial y \partial x} = 0$

2D irrotational flow of a constant density fluid

Let's suppose, that:

$$\nabla \times \vec{v} \Big|_z = \frac{\partial v}{\partial x} - \frac{\partial u}{\partial y} = 0$$

$$\frac{\partial \psi}{\partial x} = -v \quad \text{and} \quad \frac{\partial \psi}{\partial y} = u$$

$$\frac{\partial^2 \psi}{\partial x^2} + \frac{\partial^2 \psi}{\partial y^2} = 0$$

ψ is also a harmonic function.

Complex potential (1)

Both ψ and ϕ are harmonic functions: $\Delta \psi = 0$ and $\Delta \phi = 0$

furthermore they fulfill the Cauchy-Riemann conditions:

$$u = \frac{\partial \phi}{\partial x} = \frac{\partial \psi}{\partial y} \quad v = \frac{\partial \phi}{\partial y} = -\frac{\partial \psi}{\partial x}$$

Therefore they can be regarded as the real and imaginary parts of a differentiable complex function:

$$w = \phi + i\psi \quad w \text{ is called complex potential.}$$

$$w = f(z) \quad z \text{ is a complex number (position vector); } z = x + iy$$

Thus, any differentiable complex function corresponds to valid 2D, steady, irrotational flow of a constant density fluid.

We only need to look for solutions fulfilling the boundary conditions. We will analyze the complex potential of some primitive flow structures, then we superimpose and transform these simple solutions for obtaining solutions which fulfill more complex boundary conditions.


Complex potential (2)

Velocity is a complex vector as well:

$$v = v_x + i v_y$$

The complex conjugate of the velocity vector can be obtained by taking the derivative of the complex potential:

$$\frac{dw}{dz} = \frac{\partial w}{\partial x} = \frac{\partial w}{\partial iy} = v_x - i v_y = \bar{v}$$



Potentials

	ψ	ϕ	w
Name	Stream func.	Velocity-pot.	Complex-pot.
Variable density flow	N.A **	applicable	N.A
Rotational flow	applicable	N.A	N.A
3D flow	vector	scalar	N.A
Definition	$\nabla \times \vec{\psi} = \vec{v}$	$\nabla \phi = \vec{v}$	$w = \phi + i\psi$


** Another definition of ψ allows compressibility.

Parallel flow

$w = Cz$ C is a complex number.

$$w = (C_x + iC_y)(x + iy) = \underbrace{C_x x - C_y y}_{\phi} + i \underbrace{(C_y x + C_x y)}_{\psi}$$

E.g: the streamline $\psi=0$ is a straight line passing through 0,0 :



$$y = -\frac{C_y}{C_x} x$$

We can calculate the velocity:


$$\vec{v} = \frac{dw}{dz} = C = C_x + iC_y$$

Free vortex 1.

$w = iC_0 \ln z$ C_0 is a real number.

$$w = iC_0 \ln(r e^{i\vartheta}) = \underbrace{-C_0 \vartheta}_{\phi} + i \underbrace{C_0 \ln r}_{\psi}$$

Streamlines are concentric circles: $\psi = C_0 \ln r = \text{Const.}$



Free vortex 2.

The velocity field

$$\bar{v} = \frac{dw}{dz} = i \frac{C_0}{z} = i \frac{C_0}{r e^{i\vartheta}} = i \frac{C_0}{r} e^{-i\vartheta}$$

$$\bar{v} = \frac{C_0}{r} i (\cos(-\vartheta) + i \sin(-\vartheta))$$

$$v = \frac{C_0}{r} (\sin \vartheta - i \cos \vartheta) \quad \text{Unit vector pointing in azimuthal direction.}$$

The velocity magnitude: $v_{\vartheta} = \frac{C_0}{r}$

Circulation along any curve which passes around the origo one time:

$$\Gamma = 2 r \pi v_{\vartheta} = 2 r \pi \frac{C_0}{r} = 2 \pi C_0 \quad \text{thus:} \quad C_0 = \frac{\Gamma}{2 \pi}$$

Problem #2.1

What is the shape of the water surface above the drain of the bath tub? Determine the drop of water level between points characterized by r_1 and r_2 for a given value of Γ !


$v_z \approx 0$ the field variables depend only on r .

To the solution

Sources and sinks

Note that, these are line sources in 3D.

$$w = C_0 \ln z \quad C_0 \text{ is a real number.}$$



$$w = C_0 \ln(r e^{i\vartheta}) = \underbrace{C_0 \ln r}_{\phi} + i \underbrace{C_0 \vartheta}_{\psi}$$


$$z = x + iy \quad \longrightarrow \quad \psi = C_0 \operatorname{atg} \frac{y}{x}$$

$$\bar{v} = \frac{dw}{dz} = \frac{C_0}{z} = \frac{C_0}{r} (\cos \vartheta - i \sin \vartheta)$$

$$v = \frac{C_0}{r} (\cos \vartheta + i \sin \vartheta) \quad \text{Unit vector of radial direction.}$$

$$Q \left[\frac{m^2}{s} \right] = \psi_{\vartheta=2\pi} - \psi_{\vartheta=0} = C_0 2\pi \quad \text{therefore:} \quad C_0 = \frac{Q}{2\pi}$$

Problem #2.2



- Construct the complex potential for this flow! (Q , h and L are given.)
- Determine the velocity magnitude in B!
- What is the volume flow-rate between A and B?
- Calculate the pressure distribution along axis x for Darcy flow of a given permeability and viscosity!

To the solution

Flow around a corner


$$w = \frac{C_0}{n} z^n \quad C_0, n: \text{real numbers, and } n > 0.$$

$$w = \frac{C_0}{n} r^n e^{in\vartheta} = \frac{C_0}{n} r^n (\cos n\vartheta + i \sin n\vartheta)$$


$$\psi = \frac{C_0}{n} r^n \sin n\vartheta$$

$$\psi = 0, \text{ when } \vartheta = 0, \frac{\pi}{n}, \frac{2\pi}{n}, \dots$$

$n=2$:
 $\Psi=0$, when
 $0, \pi/2$



$n=2/3$:
 $\Psi=0$, when
 $0, 3\pi/2$




Problem #2.3

- What is the shape of the streamlines close to a stagnation line?
 $y=f(x)$
- How does the velocity of a fluid parcel approaching the stagnation line changes with distance?
 $v_y=g(y)$

To the solution

Dipoles (doublets) (1)



$\delta \rightarrow 0, Q \rightarrow \infty, Q \cdot \delta = \text{const.}$

$$w = \frac{Q}{2\pi} [\ln(z + \delta) - \ln(z - \delta)]$$

$$\bar{v} = \frac{Q}{2\pi} \left[\frac{1}{z + \delta} - \frac{1}{z - \delta} \right]$$

$$\bar{v} = \frac{Q}{2\pi} \frac{z - \delta - (z + \delta)}{z^2 - \delta^2}$$

$$w = \frac{M}{z}$$

$$\bar{v} = -\frac{Q\delta}{\pi} \frac{1}{z^2 - \delta^2} = -\frac{M}{z^2}$$

Problem #2.4

- Prove that the streamlines are circular, and touching upon the x axis from the positive y direction, in the origin of the coordinate system!
- Please, sketch the streamlines!

To the solution

Flow around a circular cylinder (1)

$$w = C_0 z + \frac{M}{z}$$

$$w = C_0 r e^{i\vartheta} + \frac{M}{r} e^{-i\vartheta} = C_0 r (\cos \vartheta + i \sin \vartheta) + \frac{M}{r} (\cos \vartheta - i \sin \vartheta)$$


$$\Psi = \left(C_0 r - \frac{M}{r} \right) \sin \vartheta$$

What is the equation of the streamline characterized by $\Psi=0$?

$\vartheta = 0$ line and the central circle of radius R, for which: $C_0 R - \frac{M}{R} = 0$

$$\frac{M}{C_0} = R^2 \quad \longrightarrow \quad w = C_0 \left(z + \frac{R^2}{z} \right)$$

Flow around a circular cylinder (2)



$$w = C_0 \left(z + \frac{R^2}{z} \right) \longrightarrow \bar{v} = C_0 \left(1 - \frac{R^2}{z^2} \right)$$

$$\bar{v}|_{r=R} = C_0 \left(1 - \frac{R^2}{R^2} e^{-2i\vartheta} \right) = C_0 (1 - \cos 2\vartheta + i \sin 2\vartheta)$$

Flow around a circular cylinder (3)

$$\bar{v}|_{r=R} = C_0 (1 - \cos 2\vartheta + i \sin 2\vartheta)$$

$$|v|_{r=R}^2 = (v \bar{v})|_{r=R} = C_0^2 [(1 - \cos 2\vartheta)^2 + \sin^2 2\vartheta]$$


$$|v|_{r=R}^2 = C_0^2 \left[1 - 2 \cos 2\vartheta + \underbrace{\cos^2 2\vartheta + \sin^2 2\vartheta}_1 \right]$$

$$|v|_{r=R}^2 = 2C_0^2 [1 - \cos 2\vartheta]$$

$$|v|_{r=R}^2 = 2C_0^2 \left[\underbrace{\cos^2 \vartheta + \sin^2 \vartheta}_1 - (\cos^2 \vartheta - \sin^2 \vartheta) \right]$$

$$|v|_{r=R}^2 = 4C_0^2 \sin^2 \vartheta \longrightarrow |v|_{r=R} = 2C_0 |\sin \vartheta|$$

Problem #2.5




- Calculate v_A for a given v_∞ !
- Determine the distribution of the pressure coefficient over the surface of the cylinder: $v = i(\vartheta)$.

To the solution

Flettner rotor (1)


$$w = \bar{v}_\infty \left(z + \frac{R^2}{z} \right) + i \frac{\Gamma}{2\pi} \ln z$$

$$\frac{\Gamma}{v_\infty 2R\pi} = 1.6$$




Kutta-Joukowski theorem:

$$F_l = \rho v_\infty \Gamma$$



Flettner rotor (2)



[<http://hu.wikipedia.org/wiki/Magnus-effektus>]


Problem #2.6

What circulation intensity is necessary for shifting the stagnation point by ϑ_0 angle?

To the solution

Joukowski transformation (1)

We transform the z space, but we keep the value of the complex potential: $w(z) = w(\zeta)$



By using the complex potential of a Flettner rotor, we can describe the flow around an airfoil.

Joukowski transformation (2)

A complex transformation is **conformal**, if it does not change the far field characteristics of the function. These transformations can be written in the form of a series:

$$\zeta = f(z) = z + \frac{a_1}{z} + \frac{a_2}{z^2} + \frac{a_3}{z^3} + \dots \quad \text{in which } a_1, a_2, a_3, \dots \text{ are complex numbers.}$$


The simplest possible case is the Joukowski transformation:

$$\zeta = z + \frac{a_{10}}{z} \quad \text{in which } a_{10} \text{ is a real number.}$$

Singular points (1)

In those points where the derivative of the transformation expression is zero, the inverse transformation is not single valued.

A simplified illustration for a real-real transformation:




$$\zeta = z + \frac{a_{10}}{z} \longrightarrow \frac{d\zeta}{dz} = 1 - \frac{a_{10}}{z^2} = 0$$

The singular points are on the real axis in: $z = \pm\sqrt{a_{10}}$

Singular points (2)

The transformed images of the singular points:

$$\zeta = \pm\sqrt{a_{10}} + \frac{a_{10}}{\pm\sqrt{a_{10}}} = \pm 2\sqrt{a_{10}}$$




Joukowski airfoils are images of circles passing at least through one of the singular points.


Problem #2.7


Please, specify the equation of a circle around the complex point ϵ , passing through the real point $\sqrt{a_{10}}$.


To the solution

Joukowski profiles (1)










Problem #2.8


Estimate the lift coefficient (c_L) of an arched plate!
 α and f/h can be regarded as given values, with both being small.



$$c_L = \frac{F_L}{\frac{\rho}{2} v_\infty^2 A}$$


To the solution

Comparison with measured data



$$c_L = \frac{F_L}{\frac{\rho}{2} v_\infty^2 A}$$

$$c_D = \frac{F_D}{\frac{\rho}{2} v_\infty^2 A}$$



Lift and drag coefficients for a Joukowski profile
 [Schlichting 1.11]

Application examples

Department of Fluid Mechanics, BME

Department of Fluid Mechanics BME

Oil wells (1)

The top part of the slide contains two schematic diagrams. The left diagram, labeled 'WATER CONING', shows a wellbore with a screen at the bottom. The water level in the well is rising, and the water table in the surrounding reservoir is being drawn up towards the wellbore. The right diagram, labeled 'WATER CRESTING', shows a wellbore where the water level is high, causing the water table to rise above the wellbore's screen. Below these diagrams is a cross-section of a wellbore. The wellbore is filled with water. Above the water is a layer of oil, and above the oil is a layer of gas. The wellbore is shown intersecting the oil and water layers.

Oil wells (2)

A Hele-Shaw experiment

[Ongoing research led by Prof. Tamás Lajos]

The photograph shows a laboratory setup for a Hele-Shaw experiment. It consists of a glass channel with a porous medium inside. A fluid is being injected into the channel, and its flow is being observed. The setup is supported by a metal frame and includes various tubes and containers.

Onshore water wells


The diagram shows a cross-section of a river and a well. The river is on the left, and the well is on the right. The well is shown as a vertical pipe with a screen at the bottom. The water table is shown as a dashed line. The critical flow rate depends on:

1. River level
2. The sustainable permittivity of the infiltration surface
3. Critical velocity around the pipes for avoiding damage in the porous medium.

The diagram also includes a photograph of a wellhead and two cross-sections of a wellbore showing the water table and the wellbore's position relative to the river.

Guber József Water Reservoir Budapest


The plans of a state of the art water reservoir operating in Munich was adapted by the Budapest water company in 1970.




2 piano shaped reservoirs 40.000 m³ each.

Operating modes


Munich
Continuous flow.
The total amount of water produced by the supplier passes through the reservoir.




Budapest
Used for network pressure stabilization.
Loaded by night, and unloaded during the peak consumption hours.



Professor József Gruber (1915-1972)




Proposed the idea of irrotational flow as a design target. He also suggested a method for finding an analytical solution for the irrotational flow field.




Infinite series of sinks

Department of Fluid Mechanics BME

 Laboratory experiments

Variable inlet comb



The diagram shows a cross-section of a variable inlet comb. It features a vertical inlet on the left with an upward arrow. The flow is directed into a curved duct. Two cases are shown: 'Budapest' (red arrows) and 'München' (blue arrows). The Budapest case shows a more uniform flow profile, while the München case shows a profile with a significant peak near the top. Streamlines are shown as curved arrows originating from the inlet and moving towards the right.

- Experimental setup
- Inlet comb with uniform perforation
- The Munich case
- The Budapest case

Department of Fluid Mechanics BME
